

Aerocloner Assembly Instructions vers 1.1

By Stinkbud

Step 1 – Cutting the ½” PVC Pipe

- 1) Cut eight 7” lengths .
- 2) Cut two 1½” lengths.
- 3) Cut one 2¼” length.

Step 2 – Preassemble Your Sprayer Frame

- 1) Start with the top “H”. It’s made from the 3 – Tees & two 1½” pipes.
- 2) Add the elbows to the tips of the “H”.
- 3) Add the 7” legs and end caps.
- 4) Attach the 2¼” pump connecting pipe to bottom of the “H”.

Step 3 – Drilling the Sprayer Holes

- 1) Measure and mark the sprayer holes according to the plans.
- 2) Use the 11/64” drill bit for the eight holes.

Step 4 – Drilling the Lid

- 1) Measure out 23 holes as shown in the plans.
- 2) Use the 2” hole saw to cut the holes.
- 3) Use the Exacto Knife to clean up the holes.
- 4) Cut a small hole with the Exacto knife just big enough for the cord to fit through.

Step 5 – Final Assembly

- 1) Place the pump and sprayer unit into the container and check to make sure everything fits well.
- 2) Take apart the sprayer unit and paint primer on the ends of the pipes and inside the fittings.
- 3) Start the final assembly on the sprayer unit. Be careful because the glue dries fast! Do only one part at a time until the unit is completely assembled.
- 4) Screw in the sprayers. You may need to use a pair of pliers to get them in.
- 5) Cut down a neoprene collar to the size of the cord hole you cut in the lid.
- 6) Run the cord through the lid and neoprene collar. Don’t put the lid on yet.

Step 6 – Setup and Conclusion

- 1) Add enough water to cover the pump but don’t fill it over half way. We don’t want the roots to hang in the water.
- 2) Add 150ml of Clonex solution to the water (optional) and adjust the PH to 5.8
- 3) Set your cycle timer to one minute on and five minutes off.
- 4) Put the lid on the container.
- 5) Fill the cloner with your favorite strains. **Don’t** spray the cuttings.
- 6) Enjoy your new cloner!!!! You should see roots within a week.
- 7) Don’t forget to pass the love on...